## **Noise Manual**

SV Modular



October, 2019

Noise Manual October, 2019

## Noise



Figure 1: Noise Image

SV Modular 2

Noise Manual October, 2019

**NOISE** is a simple noise generator, offering *white* noise and *pink* noise.

**NOISE** has a single input, GATE, which allows noise to be generated. When GATE accepts a signal at or above 1.7, it generates the selected noise and outputs via OUT.

Noise can be chosen between white and pink.

SV Modular 3