K Manual

SV Modular

**SV MODULAR**

K

Figure 1: K Image

K is a simple and small compressor.

K has one `IN` input, and a single `OUT` output. THR or Threshold specifies the voltage threshold for the compressor to kick in.

`RATIO` specifies the ratio to scale any values above the threshold.

ATT or Attack specifies the attack value in milliseconds to allow for the compression envelope to activate.

REL or Release specifies the release value in milliseconds to allow for the compression envelope to activate.