
Pan Manual

SV Modular



October, 2019

Pan



Figure 1: Pan Image

PAN allows for a single input to pan between two outputs.

PAN takes a value from **IN** and allows a selection via **CV** and knob to control which output (or both) to send the value. Each **OUT** output provides one side of the panned output.